

OPTICAL BRINELL HARDNESS TESTER



MODEL - VB 3000

OVERVIEW:

- VERTEX make Brinell Hardness Testing Machine is most suitable for measuring the hardness of castings, forgings & metals of all kinds.
- This machine is easy to operate & designed to maximixe the production.
- Hydraulic power pack with control circuit is provided for effortless loading & unloading through hand lever.
- A dial gauge is fitted on the front side to measure the depth of penetration.
- Microscope with 25 X magnification is provided for measuring Brinell impressions.
- This machine confirms to IS: 2281 / 1983 and BS 240.



OPTICAL BRINELL HARDNESS TESTER



MODEL - VB 3000 (O)

OVERVIEW:

- VERTEX make optical Brinell Hardness Testing machine is a production testing Machine.
- Operation of the machine is similar to the VB 3000.
- Swiveling mechanism of the ball indentor, Built-in optical systems with 14 x magnification & projection screen with micrometer of least count 0.01 mm are the additional features of this machine.
- This helps the operator to measure the impression directly on the screen without moving the job.
- This machine confirms to IS: 2281 / 1983 and BS 240.

OVERVIEW:

Model VB-3000 (M)

- This machine is simple in design, loading & unloading is through a manually operated hand lever.
- It is suitable for testing wide range of materials, flat, round or irregular shape.
- Microscope with 25 X magnification is provided for measuring of Brinell impressions.
- This machine confirms to IS: 2281 1983 & BS 240.



OPTICAL BRINELL HARDNESS TESTER

TECHNICAL SPECIFICATION:

Model	VB-3000	VB-3000(O)	VB-3000(M)
	500+3000 in	500+3000 in	500, 750, 1000,
Loads in Kgf	stages of 250	stages of 250	1500, 2000,
			2500, 3000
Initial Load in Kgf	250	Nil	Nil
Max Test Height x Throat (mm)	380 x 200	380 x 200	220 x 150
Machine height mm (Apprx)	1155	1235	870
Size of base mm	20E v 7E /	20E v 74E	275 v 505
(Apprx)	385 x 754	385 x 745	275 x 505
Net weight Kg	325	425	210
(Apprx)	325	425	210
Drive motor Hp	0.33	0.33	
Mains Supply	415V, 50 Hz	415V, 50 Hz	
	3ph A/c	3ph A/c	
Indentation	By separate	Direct reading	By separate
Measurement	microscope	on projection	microscope
		screen	

STANDARD ACCESSORIES:

Model	VB-3000	VB-3000(O)	VB-3000(M)
Testing table Ø200mm	1 no.	1 no	
Testing table Ø50mm			1 no.
V groove table for round	1 no.	1 no.	1 no.
jobs from 10 to 80 mm			
Ball holder 5 mm	1 no.	1 no.	
Ball holder 10 mm	1 no.	1 no.	1 no.
Test block HB - 5/750	1 no.	1 no.	
Test block HB - 10/3000	1 no.	1 no.	1 no.
Microscope	1 no.		1 no.
Allen keys	1 set	1 set	1 set
Steel ball 5 mm	5 nos.	5 nos.	
Steel ball 10 mm	5 nos.	5 nos.	5 nos.
Instruction manual	1 book	1 book	1 book